



NOW IN STOCK



CHASSIS PARTS CHASSIS PARTS CHASSIS

FOR THE FOLLOWING MODELS:

MODEL	DESCRIPTION	PART NUMBER
VY/VU/VX Commodore	Front Sway Bar Link	424209
VZ Comm WK/WL Statesman	Front Sway Bar Link	424210
VY 1 Tonner & Crewman, VZ Sedan, Wagon & Ute, WK/WL Statesman	Front Sway Bar Link	424211
AU/BA Falcon Sedan, Wagon, Ute, Fairlane & LTD	Front Sway Bar Link	424212 (L/H)
AU/BA Falcon Sedan, Wagon, Ute, Fairlane & LTD	Front Sway Bar Link	424213 (R/H)
GU Patrol & Ute C & Ute	Front Sway Bar Link	424214 (L/H)
GU Patrol & Ute C & Ute C	Front Sway Bar Link	424215 (R/H)
GQ Patrol/Maverick LWB/SWB Wagon & Coil Sprung Utes	Front Sway Bar Link	424216

There are seven new part numbers in the Pedders sway bar ball link range.

It's important to note that the 424209 Commodore link features specially designed polyurethane bushes to improve articulation which is a major factor in the failure of the O.E. product.



For further information please contact your local Pedders expert or check out www.pedders.com.au

Pictured above is the 424209 which is suitable for the Holden VX/VY/VU Commodores.