

NOW IN STOCK

PEDDERS

| **BUMPSTOP**

Pedders Universal Bump / Boot Kits

Pedders Part Number	A: Shock Shaft Size (mm)	B: Bump Stop Length (mm)	C: Overall Length (mm)	D: Boot ID (mm)
514001	12	45	190	50
514002	14	45	190	50
514003	16	50	210	70
514004	18	50	230	55
514005	20	50	230	55

All modern light vehicles will have some form of suspension travel limiting devices, more commonly known as "Bump stops". They are fitted to protect the steering and suspension components of your car.

Bump Stops are a very important, integral part of the suspension system. Pedders now have available, five new additional part numbers of universal bump stop/boot kits that suit a large range of vehicles.

They are constructed of a high quality energy absorbing rubber, which is an important factor for their correct function and durability.

Bump/Boot kits have three functions:

- Absorb impact energy when the wheel hits a large bump
- Protect the shock Absorber from damage
- The boot keeps dirt and road grime off the shaft, which can extend the life of the Shock Absorber



All photos used are for illustrative purpose only.

For further information please contact your local Pedders Suspension specialist or check out www.pedders.com.au Note: See our Pedders Suspension catalogue for up to date information.