



PEDDERS NEW PRODUCT

NOW IN STOCK



PEDDERS SHOCK ABSORBERS

SPRINGSSPRINGSSPRINGSSPRINGSSPRI

Pedders ComfortGas Shock Absorbers			
Part #	Make	Model	F/R
120216	VW	Transporter 03-On T5	R

120216

Pedders Suspension is proud to release a ComfortGas Shock to suit the rear of the VW Transporter. The 120216 has been specifically designed for those owners of working vans or campers where the original shock is found not be suitable for ongoing tasks at hand such as load carrying. The 120216 shock is especially suited to Pedders 7891 Heavy Duty rear coils to assist in reducing body roll and float.

The Pedders Comfort Gas Shock Absorber system has a unique nature of the oil flow process which provides a progressive response to ever changing road conditions. Unlike existing "position sensitive" shock absorbers that switch between firmer and softer control, Pedders VRD shocks provide a progressive shock response rate throughout the full range of shock travel.



For further information please contact your local Pedders Suspension specialist or check out www.pedders.com.au
 Note: See our Pedders Suspension catalogue for up to date information.