

**NOW IN STOCK**



**PEDDERS**  
**SUSPENSION BUSHES**

**BUSHES BUSHES BUSHES BUSHES BUSHES**

<b>Pedders Strut/Shock Mounts</b>			
<b>Part #</b>	<b>Make</b>	<b>Model</b>	<b>F/R</b>
580054	Ford	Focus 05-On LS	F
580054	Mazda	Mazda 3 04-08 BK1 Excl MPS	F
580050	Toyota	Camry 87-93 SV20-22 & Tarago 90-00 TCR	F
580051	Toyota/Lexus	Camry 92-97 V10, Lexus ES300 92-96	F
580052L/R	Toyota/Lexus	Camry 97-02, ES300 96-01, Avalon 00-06	F
580042	Toyota	Camry 97-06	R
580049	Toyota	Celica 94-99 ST202/204/205	F
580053	Toyota	Prado 02-09 120 Series	F
580055	Volvo	740/760 & 780 Series 84-92, 940 & 960 90-98	F
580056	Volvo	850 91-96, C70 97-02, S70, S80 97-06, V70 97-On, XC70 00-On	F
580057	Volvo	850 91-96, C70 97-02, S70, S80 97-06, V70 97-On, XC70 00-On	R
580054	Volvo	C30 07-10, S40 Sedan, V50 04-On Wagon	F

Pedders have expanded its range of rubber shock absorber mounts to include the aforementioned part numbers suitable for the listed vehicle makes and models. Designed as a direct replacement for existing strut/shock mountings, Pedders rubber shock mounts offer outstanding suspension noise, vibration and harshness suppression. The installation of Pedders rubber shock absorber mounts is highly recommend when installing new shock absorbers to a vehicle or as a solution to sagged or failing suspension mounts.



For further information please contact your local Pedders Suspension specialist or check out [www.pedders.com.au](http://www.pedders.com.au) Note: See our Pedders Suspension catalogue for up to date information.

